A Higher Level of Performance



Manual

OptioLaser S300 Liquid Laser Sensor



For more information, please visit > www.hawkmeasure.com



# Table of Contents OptioLaser S300 Liquid Laser Sensor



# Contents

Overview	3
Introduction	3
System Components	4
OptioLaser S300 series comes standard with the laser already installed inside the ruggedized housing plus	4
Dimensions	5
OptioLaser	5
Ruggedized 4" Flange Tank Adapter	5
Flange and Dust Tube Assembly	6
Getting Started	7
Measurement Technique	7
Wiring the Unit	8
OptioLaser	8
Wiring 4-20mA Output / HART	9
Sinking Type Output (2 wire loop powered)	9
Incorrect Mounting	10
Correct Mounting	11
Installation Guide	12
•••••••••••••••••••••••••••••••••••••••	• • •

Configuration	13
Computer Interface	13
Terminal	13
Configure Sensor	14
Targets Tab	14
Target Fluid Characteristics	14
Data Rate Tab	15
4-20mA Tab	15
Configuration Examples	16
Tank Measurement	16
Liquid Measurement	17
Liquid Measurement Consideration	17
HART Communication	18
Frequently Asked Questions	19
Sensor FAQs	19
General Sensor Information	20
Certifications	23
Care and Maintenance / Specifications	24
Operating Temperature	24
Moisture Protection	24
Cleaning	24
Specifications	24





# Introduction

Thank you for purchasing the HAWK OptioLaser.

The OptioLaser S300 Series is user configurable, allowing for optimized performance of your application. The OptioLaser uses an infrared semiconductor, GaAs laser diode. A light energy wavelength of approximately 905 nanometers, with a beam divergence of 3 milliradians (equal to 3ft at 1000ft), travels to the fluid being measured. Any liquids in its path will reflect back a certain percentage of emitted light energy. The OptioLaser calculates the distance, based on the time it takes a laser pulse to travel to the liquid and back.

	Description	Part Number
Ontiol apor	OptioLaser S300 series	OL70068XX
OptioLaser	Serial to USB adapter	OLXXXX
	AC to DC Power Cable	OL7054691
	Description	Part Number
Remote indication	Handheld calibrator / programmer	OLTRT438008
	Wall mount display	OLPD260006H7
	Description	Part Number
Accessories	Tank Adapter	OL7035146
	4" Flange	OL3004960
	Diffuser Lens	OL7024972
	Spanner Wrench (necessary for tightening tank adapter)	OL9034501
	Swivel Mount	OL3004959



• The Class 2 Alignment Laser Exit Aperture is located on the upper portion of the Front Plate between the Transmit and Receive Lenses of the Class 1 Measurement Laser.





# OptioLaser S300 series comes standard with the laser already installed inside the ruggedized housing plus

- Serial to USB adapter
- AC to DC power adapter



# Outputs for each model

	I/O				
Models	Visible Alignment Laser	RS232	4-20	4-20 HART	Trigger
S300					
S310					
S330					



# Dimensions OptioLaser S300 Liquid Laser Sensor



# **OptioLaser**



# Ruggedized 4" Flange Tank Adapter





# Flange and Dust Tube Assembly

OptioLaser S300 Liquid Laser Sensor



1

Attach tank adapter to lens side of laser, via set screws



Screw the 4 inch flange fully onto the tank adapter (as far down as it will go until the parts are tightly fastened).











Tank Adapter



Ruggedized Enclosure





- It is recommended to get familiar with the sensor performance and configuration in a controlled environment.
- After unpacking, power up the unit with the supplied cabling and connect the DB9 pin serial connector to a serial I/O devise such as a PC.
- A DB9 to USB adapter and power and communication cable is included with the unit from Hawk Measurement.
- When using the OptioLaser, communicate using either the supplied interface software, a terminal emulation program such a HyperTerminal or HART, depending upon your options.
- Default = 115200 baud rate, no parity, 8 data bits, 1 stop bit, no flow control.

#### **Measurement Technique**

#### Seeing a Target

The OptioLaser uses infrared laser light to measure distance. This invisible light emits from the transmitter lens of the sensor, reflects off the liquid and returns to the receiver lens. The distance is calculated by comparing this transit time.

The ability of a laser sensor to measure to a liquid depends on the fluid's reflectance and any interference between the sensor and target such as steam, fog, etc. Reflectance is determined by color, opacity, distance, angle of reflection, as well as the density of any ambient interference between the sensor and the liquid. For example, a lighter colored liquid is more reflective than a clear one; heavy steam will reduce the signal strength more than a light mist.

The OptioLaser S300 can measure any liquid within its specified range, even penetrating steam and mist. A good rule of thumb when measuring with a laser: if you can visibly see the target, the laser can as well.

#### **Window Application**

When measuring through a window, ensure the face plate of the sensor is 3mm or closer to the window, since reflections will increase with a larger gap and could result in measurement error, due to "cross-talk". Cross-talk occurs when a reflection from a very close reflector (like a window) is combined with the actual target reflection, leading to an inaccurate measurement.

#### **Beam Diameter**

Beam Diameter at the Target = Free Aperture + (Divergence x Range) Free Aperture = 23mm Divergence = 3mrad Distance to target = 100m Beam Diameter at the Target = 0.023 + (0.003 x 100) = 0.323m Therefore, Beam Diameter is 32.3 cm (12.7") at 100m (328ft)



# Wiring the Unit OptioLaser S300 Liquid Laser Sensor



# OptioLaser

The OptioLaser has wiring information printed inside the rear cover of the unit.

#### Ensure your power source is deactivated

- Unscrew the rear cover to expose the terminal block to access the wiring.
- Pass cables through the cable entry gland before wiring into the terminal block.
- Tighten cable entry gland(s) and cover to ensure sealing is effective.









# Wiring 4-20mA Output / HART

OptioLaser S300 Liquid Laser Sensor



Please note: The OptioLaser 4-20mA output is passive, thus it requires 24VDC from a user device such as a PLC input, DCS or indicator in order to function.

# Sinking Type Output (2 wire loop powered)



OptioLaser output is sinking current. Voltage to drive current loop must be provided by PLC, indicator, other user device or external DC supply.



Incorrect Mounting OptioLaser S300 Liquid Laser Sensor



These are examples of common INCORRECT mountings which can prevent the unit from operating correctly

Do NOT mount near





Do NOT mount over or adjacent to any obstacles





# Correct Mounting OptioLaser S300 Liquid Laser Sensor



# Recommended installation of laser is at least 1 ft (25 cm) away from tank wall









#### Laser

- Selecting a suitable position to mount the laser is the single MOST IMPORTANT step.
- Please read the installation guide or contact HAWK representative if you have any doubts or questions. Observe minimum range specification of 1.5ft.
- Use common sense when selecting the mounting position. A clear line of sight is required.
- Take into account the change in material shape and level. The laser must reflect back to the receiver.
- Keep away from the inflow to avoid interference.

#### **Process Conditions**

• Ensure the process conditions within the vessel such as temperature, pressure and chemical composition of contents are within the unit's specifications. The unit should not normally come into contact with the measured content.

#### **Moisture Seal**

• Cable glands with moisture seals must be used and tightened around the cable. Any unused glands must be sealed.

#### **Moisture Protection**

• The lenses of the sensor should be kept clear of excessive contamination for optimal performance.

#### Cleaning

- Excess Moisture: Towel off excess moisture and air dry the instrument at room temperature.
- · Exterior Dirt: Wipe exterior surfaces clean
- Dirty Lenses: Use a lint free soft cloth to remove surface dust and loose particles from transmit and receive lenses. To clean a lens, moisten it with lens cleaning solution and wipe it clean with a lens cloth or lens tissue.



After the unit has been installed, mounted and powered you can now enter the settings to get the unit operational in your application conditions. To start configuration, you will need to have the following information:

- Blanking Zone (at least 1.5 ft (46 cm) or greater)
- End of Blanking Zone
- High Level
- · Product Level being measured
- · Low Level





# **Computer Interface**

- · Device: Model
- SN: Device serial number
- Red "Laser On": Laser is firing
- Counter: Measurement count
- · Enable Visible Laser Pointer: Alignment laser
- Disconnect: Terminates communication stop
- · Start / Stop Measurement: Laser starts / stops measuring
- EXIT: Exits programming
- Terminal: Brings up Terminal Mode. User can type in commands and see response as well as scrolling data as the sensor is measuring
- · Configure Sensor: Accesses setup menus.

### **Terminal**

- · User may enter commands in the lower window. The data scrolls in the main window
- · Dump Parameters: Scrolls the settings in the sensor for review
- · Send Command: Sends commands entered in input window to laser
- Clear: Clears commands entered in input window.





# **Configure Sensor**

- · The interface will read the configuration from the sensor
- Measurement Mode: Selection based on the maximum range.
- Range Units: User may select measurement units.
- Offset: Adds or subtracts from overall measurement.
- · Autostart: Enable Autostart for sensor to automatically begin measuring on power up.
- · Load Device from File: Upload file settings from saved file to sensor.
- · Backup Device: Save Current Sensor settings to file.
- Restore Factory Defaults: Load settings from the factory from non-volatile memory.
- · Apply & Save to File: Load menu settings to sensor and save file.
- Apply & Exit: Save menu settings to sensor and exit programming.
- Exit: Exit programming and return to measurement mode.

# **Targets Tab**

• Target Selection: Target Discrimination Menu. User selects target based on application.

**FIRST:** The measurement output represents the distance to the first target the units sees that is above the minimum detection level.

#### **IMPORTANT:**



Not to be chosen when using the ruggedized housing

**STRONGEST:** The measurement output represents the distance to the strongest target the unit sees that is above the minimum detection level.

**LAST:** Multiple target operating mode. This allows the unit to detect multiple target reflections along the measurement line, allowing weaker distant targets to eventually be detected beyond stronger (closer) targets. Example: measuring liquids thru mist and steam.

# **Target Fluid Characteristics**

- · Slow moving water / small waves
- Rough water / Large waves
- Flat surface / still tube





# **Data Rate Tab**

- User selects data update rate. In this example, the update is set to 1Hz or 1 measurement per second.
- User sets both windows to "0" for maximum update rate of 14Hz using these settings.
- Example #1: The user wants an update rate of 5Hz. They would enter 1 for number of measurements and 0.2 (the inverse of 5) for delay between measurements.
- Example #2: The user wants 1 reading every 10 seconds. They would enter 1 for number of Measurements and 10 for delay between measurements.

# 4-20mA Tab

- 4-20 menu allows the user to set ranges at 4 and 20 scale.
- Error current is set here as well.
- A difference of at least 6.6 ft (2m) must be between the range of 4mA and 20mA
- · After settings are made, it is necessary to Apply & Exit



# **Configuration Examples**

OptioLaser S300 Liquid Laser Sensor



These examples are not absolute - sensor setup configuration varies depending on ambient conditions, target integrity, distance, constraints, and user requirements.

## **Tank Measurement**

Consideration: Measure the liquid in a tank, thru ambient conditions such as mist and steam.



#### Summary:

- In this example, the maximum distance to the bottom of the tank is 82 ft (25 m) so the Standard Measurement Mode will yield the best accuracy.
- The sensor must be able to penetrate mist and steam inside of the tank. Choose "Last Target" for this.
- We want a measurement speed of 2Hz.
- We also want the unit to begin measuring upon power up enable Autostart.
- If the measured distance exceeds our maximum or minimum, 3.5mA will be output.

Configuration	Configuration
Measurements   Eargets   Data Rate   External Post   4 - 20 mA	Measurements   Targets   Data Rate   External Post 4 - 20 MA
Data Rate Nacibor Di Messacementis 1 (D = continuonal) Delag Bentener Messacementis 0 5 (ince (incc))	1-20 nA Carent Loop Ranges (BFT) 1 Range at Enk 2 Range at 20 mk Execution (BFT) 5 Set to 35 mA 5 Set to 35 mA 5 Set to 35 mA 1 Elser Carent Value 1 Elser 4 cank ue to 35 mA 1 Elser 2 Cank ue to 35 mA
Load Device From File Apply & Save To File	Load Device From File Apply 1 Save To File
Bachup Device Apply 5 Evit Evit	Backup Denice Apply 15 Lat
Pertore Factory Defaults	Rentove Factory Delautes
Heasannet [ Tageh ] Data Rate   Extend Plut   4 - 20 oA   Heasannet Mode (DAN 2 4005 H) Criender Range (Stilts or 4021 3 H) Intelligen Long Review (Stilts or 3014.4 H) Fange Units (Still) Fange Units (Still) Verific	Measurement, Tagets (Duta Rale ) Colond Pier) 4 - 20 mA) Taget Selecton Dupley Model - Res BOM.2) - Storgen: (IDM.2) - Last (IDM.4)
0.0 Officer (\$UC) Product (\$MAL)	



# Liquid Measurement Consideration

To measure the liquid in a tank.



In the example above, the maximum distance to the bottom of the tank is 82 ft (25 m) so the standard Measurement Mode will yield the best accuracy.

- The sensor must be able to penetrate steam or mist inside the tank. Choose "Last Target" for this.
- Set a measurement speed of 2Hz.
- Set the unit to begin measuring upon power up enable Autostart.
- If the measured distance exceeds the maximum or minimum, 3.5mA will be output.
- Each liquid will react differently and the user will need to adjust the settings for optimum performance.





Your HART compatible model allows for user communication with a HART compatible device as a Generic Device. Shown are typical parameters using a 475 hand-held controller.

Read / Write				
PV LRV	Primary Value Lower Range Value			
PV URV	Primary Value Upper Range Value			
Descriptor	Descriptor Field			
Final Assembly Number	Descriptor Field			
TAG, Long TAG, Message	Descriptor Fields			
Read Only or No Write Ability				
Read Only or No Write Ability				
Read Only or No Write Ability Burst	Maximized the data rate			
Read Only or No Write Ability Burst 4-20 Current	Maximized the data rate Reading			
Read Only or No Write Ability         Burst         4-20 Current         Range	Maximized the data rate Reading Reading			
Read Only or No Write Ability Burst 4-20 Current Range Percent of Range	Maximized the data rate Reading Reading Reading			



# Frequently Asked Questions

OptioLaser S300 Liquid Laser Sensor



# **Sensor FAQs**

#### What Type of laser does Hawk Measurement offer?

Pulsed, 905 nanometers (nm), Time-Of-Flight (TOF) lasers. 905 nm is the wavelength of the infrared light of the laser (this wavelength lies just outside the visible light spectrum that ranges from 400 nm to 730 nm).

#### How does the Hawk Measurement laser work?

The OptioLaser's transmitter lens emits pulses of light, which reflect off a target's surface, and travel back to the receiver lens. The timing of the pulse is measured, enabling the distance to be precisely calculated.

#### What data output rates do our lasers operate at?

The OptioLaser ranges from <1 Hz to 14Hz

#### What's the distinction between clear and opaque liquids to a laser?

If the water is very clear and still, an unaided laser will read through the surface to some point below the surface level. If the depth is shallow (six inches), the laser may read to the bottom of the tank or vessel. In this case, a diffuser will spread out the normally focused laser, in order to reflect off the surface of this clear liquid. The measuring range will be reduced but you will be able to provide an accurate, consistent measurement.

#### Is the laser beam eye safe?

Yes, the HAWK sensors are rated Class 1 for eye safety. But, it is always a good practice not to stare directly into the transmit aperture of any light transmitting device.



# Frequently Asked Questions

OptioLaser S300 Liquid Laser Sensor



### **General Sensor Information**

#### What is Pulse Repetition and why is it important?

Pulse Repetition Frequency (PRF): How fast the sensor is sending out laser pulses. A faster PRF can take more measurements or detect targets at higher speeds and/or use more pulses to get a better average. PRFs in the Optio is set at 2,800 PRF.

#### Is the 4-20 mA output of OptioLaser actively or passively powered?

For the OptioLaser sensor, the 4-20 mA loop is passively powered (sinking), meaning power must be supplied by an outside source.

#### Does the laser need calibrating to the specific distance it is measuring?

No, it is fully calibrated before it leaves the factory and will work to any distance within its specified range.

#### How is the laser beam diameter calculated?

Lasers produce a very narrow beam that can be precisely aimed at a target. This is just one of the features that sets laser sensors apart from other technologies.

Beam diameter over distance can be calculated as follows:

Example:

- Free aperture: 23mm
- · Divergence: 3 mrad
- Distance to target: 100m
- Calculation = 0.023 + (.003 x 100) = 0.323m

Therefore, the Beam Diameter is 32.3 cm (12.7") at a distance of 100 m (328 ft).

How large is the spot size of each of the Througher Technologies?	Model	Sensor	ENTER Tank Height (ft)	Beamwidth @ Tank Height (ft)	Needed Distance From Wall (ft)
		S300 Liquid	25	0.15	0.075
REAMDIAMETERAT SO FEET		S300 Liquid	75	0.3	0.15
LLTRASDILCOR RADAR-21.7 INCHES TOP REAM DIAMETER-2.5 INCHES	OptioLaser	S300 Liquid	150	0.525	0.2625
PARE SHIT-LENDES		S300 Liquid	300	0.975	0.4875
BORDOWLERVING 2000, NET WALTER - BARRING , WHEL		S300 Liquid	656	2.043	1.0215



OptioLaser S300 Liquid Laser Sensor



#### What are the benefits of our products in our chosen markets?

Market	Benefits
Plant Management	<ul> <li>Ruggedness</li> <li>Ability to handle harsh environments</li> <li>Ability to set target mode to optimize measurements (averaging or last mode)</li> </ul>
Water & waste water	<ul><li>Ability to measure foam or liquid level</li><li>Ability to measure through narrow opening, grates or along a wall</li></ul>
Chemical storage	<ul><li>Ability to measure liquids without being in contact with process</li><li>Ability to measure all liquids, even clear ones</li></ul>

#### Is this a proven technology in industrial applications?

Yes, lasers for material measurement have been used for industrial applications for over a decade. While relatively new compared with ultrasonic and radar, lasers have continued to expand their application base.

#### Do you need high data output rates in industrial applications?

Usually, there is no need for high output rates because processes are relatively slow; typically 10Hz or less.



OptioLaser S300 Liquid Laser Sensor



#### What are the different target modes in the OptioLaser S300 Series?

The OptioLaser S300 series has three standard target modes: first, last and strongest.

Target Mode	Definition	Recommended Use
First	The unit only measures to the first target it sees *	*Not utilized for the S300 with ruggedized housing*
Strongest	The unit measures to the strongest target it sees	When an obstruction, such as a grate, exists between the intended target and sensor
Last	The unit measures to the last target it sees	To get better results through steam and mist.

The OptioLaser S300 series also supports several advanced target modes, which can be used under specific circumstances.

Fluid characteristics:

- · Slow moving / small waves
- · Rough water / large waves
- Flat surface / still tube

#### **Can HAWK lasers penetrate foam?**

Unless the foam has a very low-density, the laser can only measure the top of the foam. However, if the customer can use a standpipe, foam dispersion system or other means to dissipate the foam, then the laser will be able to provide an accurate measurement of the liquid level.

#### Will HAWK lasers work through dense steam?

Like foam, it depends on the density and composition of the steam, as well as the nature of the surface to be measured: clear or opaque, still or turbid. As a general rule: If you can see through it, the laser can as well.

#### What considerations are there when measuring through glass?

Borosilicate glass typically works well. Also, there is no degradation using plane glass or even plastic. When measuring through glass, it is recommended the face plate of the sensor be 3mm or closer to the glass. Larger gaps could result in measurement error.

Typically, a transmission of over 90% is desirable. Uncoated glass has a 8% reflection loss per each plate. It is better if each side is coated with an anti-reflection coating, which can reduce the reflection loss to close to 0%". If there are any questions or uncertainties, the customer should get transmission curve for the glass they are considering.



# **Frequently Asked Questions**

OptioLaser S300 Liquid Laser Sensor



#### What accessories are available for the OptioLaser S300 series?

The following accessories are available:

- Flange
- Tank adapter
- · Swivel mount stand
- Power/Communications cable
- Swivel mount stand

# Certifications

#### Do we have IEC 60825-1 Certification for our lasers?

The OptioLaser is self-certified, permissible in the United States. The power levels of our lasers are within Class 1 eye safety limits.

At the highest PRF (4KHz) and highest power level (400 nJ per pulse), we meet Class 1M limits, safe unless looked at through a magnifying lens. At lower PRF settings, our lasers can be Class 1 depending on the power setting. However, the alignment laser is always a Class 2M device.

#### What is a Class 1M Laser?

A Class 1M laser is safe for all conditions of use except when passed through magnifying optics such as binoculars and telescopes.

#### What is the significance of 50mm and 7mm apertures?

The classification looks at what the eye would see when looking through an optical aid (binoculars, magnifying glass, telescope, estimated 50mm aperture) and the naked eye (7mm aperture, no optical aid).



# Care and Maintenance / Specifications

OptioLaser S300 Liquid Laser Sensor

## **Operating Temperature**

The OptioLaser is rated for temperatures of  $-20^{\circ}$ F to 140°F (-28°C to 60°C). Do not operate the instrument in temperatures outside of that range.

#### **Moisture Protection**

The lenses of the sensor should be kept clear of excessive contamination for optimal performance.

# Specifications



### Cleaning

Excess Moisture: Towel off excess moisture and air dry the instrument at room temperature.

Exterior Dirt: Wipe exterior surfaces clean.

Dirty Lenses: Use a soft lint-free cloth to remove surface dust and loose particles from transmit and receive lenses. To clean a lens, moisten it with lens cleaning solution and wipe it clean with a lens cloth or lens tissue.

	Minimum Range	1.5 feet (46 cm)
	Maximum Range	656 ft (200 m); 164 ft (50 m) for clear liquids
	Accuracy	± 1.6" (4 cm)
Porformanco	Data Output Rate	Option 1: <1 up to 14 Hz depending on target
i enormance		Option 2: Fixed 200 Hz mode
		First
	Target Modes	Strongest
		Last
	Wavelength	905 nm (infrared)
	Beam Divergence	3 mrad equal to 12.7" (32.3cm) beam dia. at 328 ft (100m)
Optical & Electrical	I/O	S300:RS232,Trigger; S310:RS232,alignment laser; S330:4- 20 HART,RS232,alignment laser
	Input Power	12-24VDC (12VDC recommended)
	Current Draw	Measuring = 150 mA, Standby = 40mA
	Dimensions	5" (12.7cm) dia. X 10"(25.4 cm) length
Physical	Weight	8 lbs. (3.62 kg)
	Housing and Frame Material	Cast aluminum, epoxy coated
	Eye Safety	Class 1, 7mm (FDA CFR21)
		Class 1m (IEC 60825-1:2001
Environmental	Shock Vibration	MIL-STD-810
	Moisture	IP54
	Operating Temperature	-20 °F to 140 °F (-28°C to 50°C)





#### HAWK, Since 1988

Hawk Measurement Systems Pty Ltd (HAWK) was established in 1988. It's founding members saw the universal requirement of various industries requiring improved process control and efficiency in their operations.

#### We Can Help

HAWK understands the difficulties customers face when seeking accurate level measurement. Every application is different, involving a multitude of environmental factors. This is where HAWK excels. Our aim is to ensure that customers feel comfortable with our technology, and are provided with long term and reliable solutions. We believe that a combination of application and product expertise, as well as forward thinking and proactive support policies are the foundation of successful customer-supplier relationships.

Hawk Measurement Systems (Head Office)

#### Progressive Technical Support

HAWK believes that the future of the Level Measurement Industry revolves around the quality of pre and post sales - support. Our aim is for all sales & support staff to be product experts, and more importantly application experts making our customers applications as efficient and consistent as possible.

#### Knowledge Sharing

HAWK believes that knowledge sharing is key to creating long term relationships. Empowering our customers and our worldwide distribution network, whilst being available at all times to lend a helping hand, is the perfect recipe for long-term solutions and relationships. HAWK openly extends an invitation to share our 25 years of level measurement experience, and ensure that your day-to-day processes are efficient, understood, and always working.

# Hawk Measurement

90 Glenn Street, Suite 100B, Lawrence, MA 01843, USA Phone: +1 888 HAWKLEVEL (1-888-429-5538) Phone: +1 978 304 3000 | Fax: +1 978 304 1462 info@hawkmeasure.com

For more information and global representatives: www.hawkmeasure.com



15 - 17 Maurice Court

Fax: +61 3 9873 4538

info@hawk.com.au

Phone: +61 3 9873 4750

Nunawading VIC 3131, AUSTRALIA